

TECHNICAL INFORMATION

KLEEN
PURGATIS

STAINLESS STEEL CLEANERS AND CONDITIONERS

PRESTAN STAINLESS STEEL MAINTENANCE



Art.-Nr. 90.203.778 12 x 0,5L bottle unit

- cares and protects all stainless steel surfaces
- maintenance, polish and protection in one step
- dirt and water resistant
- prevents fast from new soilings when used regularly
- creates a glossy protection film and finish
- rejects visible finger prints
- suitable for chrome, aluminium, brass, nickel and anodized surfaces

APPLICATION RANGE:

Prestan Stainless Steel Maintenance cleans, cares and protects all surfaces of non-corrosive steel - as well as objects made from chromium, aluminium and anodized surfaces, nickel and brass. Do not use on surfaces in direct contact with food, for example worktops in kitchen areas or food processing.

INSTRUCTIONS FOR USE AND DOSAGE:

Initial maintenance product for stainless steel and above listed materials.

Remove coarse dirt deposits of the surface to be cleaned. We recommend to use Kraftreiniger A (Power Cleaner A). After cleaning - take off chemical agents with clear water. Add Prestan Stainless Steel Maintenance to a dry cleaning cloth. Distribute evenly on surface. Take off excess of product. Do not polish again. For daily maintenance care - use product only on stains of metal surface. **If improperly applied - and for claims resulting from such improper handling - there will be no legal claims accepted.**

TECHNICAL DATA:

Form: clear colourless liquid
Odour: like solvent
Viscosity: low
Density: 790 g/l

INGREDIENTS:

Over 30 %: aliphatic hydrocarbons
Stability: at least one year in original containers

LABELING:



Gefahr



Contains low boiling point modified naphtha

Hazard statements:

H304: May be fatal if swallowed and enters airways.
H315: Causes skin irritation.
H319: Causes serious eye irritation.

Precautionary statements:

P101: If medical advice is needed, have product container or label at hand.
P260: Do not breathe vapours.
P280: Wear protective gloves.
P301+310: IF SWALLOWED: Immediately call a POISON CENTER/doctor.
P331: Do NOT induce vomiting.
P305+351+338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
P302+352: IF ON SKIN: Wash with plenty of soap/water.

TRANSPORT: No dangerous good in sense of these transport regulations (ADR).

KLEEN PURGATIS GmbH

Dieselstraße 10
D-32120 Hiddenhausen
Fon +49 (0) 5223 9970-40
Fax +49 (0) 5223 9970-195
info@kleen-purgatis.de
www.kleen-purgatis.de

**An Affiliated Company
of the BUDICH GROUP**

Sales Department International:
KLEEN PURGATIS International AG
Firststrasse 30A
CH-8835 Feusisberg
Fon +41 (0) 44 515 35 60
Fax +41 (0) 44 515 35 69
info@kleen-purgatis.ch
www.kleen-purgatis.com